


Adjustable Tire Carrier




Assembly Instructions:

Step 1:




Attach the smaller diameter rod (with 3 holes) into the base. Suggested to use Loctite to prevent unwanted loosening of base.

Step 2:



Slide the large diameter rod over the smaller rod and secure with 10x24 phillips head screw at the desired height.



Step 3:



Place tires on carrier pole, then put plastic disc on top of tires. This will keep tires in place when moving around.

Step 4:



Screw handle on to top of pole.