

SHOE SETTINGS

NOTE: Clutch illustrations shown as viewing the open end of an **INBOARD** mounting. For shoe settings on an **OUTBOARD** mounting, use the reverse shoe position.



**SETTING # 1
HEAVY AND
LIGHT SHOE**
For rapid
engagement and
low inertia starts.



**SETTING # 2
HEAVY SHOE ONLY**
For moderate to rapid
engagement and
average to low inertia
starts.



**SETTING # 3
LIGHT SHOE ONLY**
For moderate
engagement
and average inertia
starts.



**SETTING # 4
HEAVY SHOE ONLY**
For smooth, gradual
engagement and
high inertia starts.



**SETTING # 5
HEAVY AND LIGHT
SHOE**
For very smooth,
gradual engagement,
and high inertia starts.

